
















## PlayStation 2 Router Connection Setup

(A PS2 Memory card must be inserted into the PS2 before continuing)

(After the Network Card has been connected to the PS2)

1. Insert the Network Adaptor Start-Up Disc that came with the PS2 Network Card.
2. When the screen appears with Help, ISP Setup, and Demos present, if ISP Setup is not highlighted, use the right or left arrows to select ISP Setup and press the  on the controller.
3. On the following screen that displays "Now the Setup Process will begin," press the  on the controller.
4. On the following screen that displays "Found network adaptor," press the  on the controller.
5. On the following screen that displays the warning about Internet Service Providers, press the  on the controller.
6. On the following screen requesting to name your ISP setting, use the directional arrow keys or the left analog controller to insert "pdi.net" (without the quotes " "). When finished select Enter.
7. Press the  on the controller.
8. On the screen asking if you subscribe to an ISP service, if Yes is not highlighted use the directional arrow keys or the left analog controller to highlight Yes.
9. Press the  on the controller.
10. On the screen asking to choose a connection type, if High Speed Connection (Cable or DSL) is not highlighted use the directional arrow keys or the left analog controller to highlight High Speed Connection (Cable or DSL).
11. Press the  on the controller.
12. On the screen asking to choose settings, if Automatic Settings is not highlighted use the directional arrow keys or the left analog controller to highlight Automatic Settings.
13. Press the  on the controller.
14. On the screen asking if your ISP requires a User ID and Password, if Yes is not highlighted use the directional arrow keys or the left analog controller to highlight Yes.
15. Press the  on the controller.



16. On the screen asking if a DHCP host name is required, if No is not highlighted use the directional arrow keys or the left analog controller to highlight No.
17. Press the  on the controller.
18. On the screen stating you are now connected, press the  on the controller to save the settings to your memory card.
19. On the Congratulations page, press the  on the controller.
20. After it returns you to the main menu, you may insert a game compatible with online gaming and play games with others around the world.